

Land Cruiser 250 Series IMS59-60440 / MRA59-A440 Strut assembly instructions using OEM Strut top plates.



IMS59-60440

1. **Spacer (Supplied on the shock)**
2. **Concave Washer (Holds shock dust boot, Dobinsons highly recommends keeping the boot on the shock.) (Supplied on the shock)**
3. **Washer with "D" Shaped hole (Supplied in the hardware bag)**
4. **Bushing with "D" Shaped hole (Supplied in the hardware bag)**
5. **OEM Strut Top Plate (from OEM shock)**
6. **Nut (Supplied on the shocks) Tighten until the nut bottoms out.**



MRA59-A440

1. **Built-in Washer (Holds shock dust boot, Dobinsons highly recommends keeping the boot on the shock.) (Supplied on the shock)**
3. **Washer with "D" Shaped hole (Supplied in the hardware bag)**
4. **Bushing with "D" Shaped hole (Supplied in the hardware bag)**
5. **OEM Strut Top Plate (from OEM shock)**
6. **Nut (Supplied on the shocks) Tighten until the nut bottoms out.**



NOTE: In both occasions, the OEM bump stop on the shock shaft is not re-used.

**Dobinsons products should be installed by a qualified installer, and it is the installers responsibility to ensure correct fitment.
Dobinsons is not responsible for any damage incurred to the vehicle during installation.**

Strut seat height is to be set at 237mm / 9.3" from the center of the lower bushing to the strut seat.

