

RESERVOIR MOUNT BOLTED  
ON TOP OF COIL TOWER USING  
STRUT TOP CAP NUTS TO SECURE.

Holden/Chev Colorado/7/Trailblazer  
Isuzu Dmax Gen1 2012-2020

BANJO POSITION

GRIND OFF BRAKE BRACKET STUD HEAD  
WELD AND REMOVE STUD. RUN HOSE FROM  
BANJO ON CHASSIS SIDE OF STRUT UPWARD  
AND FIX WITH P-CLAMP. BOLT FIRST THROUGH  
P CLAMP THEN THROUGH BRAKE BRACKET  
ENSURING THE TAB IS ALIGNED AND THE BRACKET  
ALIGNED CORRECTLY. THE SHOCK HOSE WILL GO TO  
THE INSIDE. ENSURE AT FULL DROOP HOSE IS  
REASONABLE TIGHT WITH CLEARANCE TO SPRING  
SEAT AND SPRING.

