

# TOYOTA LAND CRUISER 300 SERIES

**BOLT THROUGH EXISTING HOLES IN CHASSIS**

**MAKE SURE THE END OF THE RESERVOIR HAS CLEARANCE BETWEEN THE NUT AND PIN OF THE SHOCK ABSORBER**



## 300 SERIES LANDCRUISER DIFF BREATHER REAR

**SLIDE DOWN**


**PULL BACK THROUGH AS MUCH AS POSSIBLE WITHOUT BENDING BRACKETS**





# **TOYOTA SEQUOIA 2023 ON**

**Use Reservoir Bracket (RM80-005)**



**Bolt through existing  
hole in the chassis**

**Drill 1/4" hole and use M6  
Bolt with nut through  
chassis**