

**Sway Bar Relocation Bracket  
Install Guide  
Part Number: SE19-612K  
Fitment: Ford Bronco 2021 on**



***This Sway Bar Relocation will take approximately 1 hour to install***

***Dobinsons products should be installed by a qualified installer, and it is the installers responsibility to ensure correct fitment.***

***Dobinsons is not responsible for any damage incurred to the vehicle during installation.***

**1. Remove the 2 bolts on each side that attach the factory sway bar brackets to the bottom of the frame.**

**2. Remove the OE studs on each side.**



**3. Install the sway bar relocation brackets with the threaded holes toward the front of the vehicle using the supplied allen head bolts.**

**Torque to 66ft/lb**



**4. When reinstalling the OE sway bar onto the relocation brackets it is important to support the OE bracket with a screw jack and ensure the holes line up and is sitting flat against the relocation bracket.**



**4. Reinstall the sway bar onto the relocation bracket using the supplied bolts.**

**Torque to 66ft/lb**

